

- Implement MATLINK coupling with MATLAB PIVlab
<https://www.mathworks.com/matlabcentral/fileexchange/27659-pivlab-particle-image-velocimetry-piv-tool-with-gui>
- Frame_1 -> Frame_001
- Improved boundary/static artifact treatment
- GPU-based BM3D filtering instead of Perona-Malik
- GPU-based NMM instead of the CPU version

In[]:= `ClearAll["Global`*"]`

Important:

For seamless automatic processing, do this:

- 1) Disable (using "Alt + /" to (un-)comment) all import cells except image import
- 2) Use memorized crop bounds (instructions below)

For checking & re-doing existing input:

Option 1: place the experiment folder with run subfolders into the 'output' folder

Option 2: change the 'mainOutputFolder' in "Initialization" to the main results folder

ALWAYS EVALUATE 'Initialization' FIRST

Initialization

```
$HistoryLength = 0;
nbd := NotebookDirectory[]

(*packageDirectory:=
"D:\\Science\\NMI (VTPMML)\\MHD Project\\Image Processing\\Mathematica
Libraries & Packages\\Quantile Regression\\"

Import[packageDirectory<>"QuantileRegression.m"];
<<MaTeX`*)

SetOptions[
ListPlot,
{Frame -> True, FrameStyle -> {Black, Bold}, TicksStyle -> {Black, Bold},
LabelStyle -> {Black, Bold, fontSize}, ImageSize -> Large}
];
```

```

SetOptions[
  ListLinePlot,

  {Frame → True, FrameStyle → {Black, Bold},
   TicksStyle → {Black, Bold}, LabelStyle → {Black, Bold, fontSize},
   PlotStyle → Automatic, Filling → None, ImageSize → Large}
];

launchNukes[useKernels_] := If[
  Length@Kernels[] < #,
  # - Length@Kernels[] // LaunchKernels,
  Nothing
] &@useKernels;

mainOutputFolder = nbd <> "Output";
CreateDirectory@mainOutputFolder; // Quiet

progress[x_, y_] := TableForm@
{
  "Processing...",
  ProgressIndicator@Dynamic[x / y // N],
  ToString@Round@x <> "/" <> ToString@y,
  ToString@PercentForm[x / y // N, DefaultPrintPrecision → 1]
}

memoryCheck[] :=
  "Memory in use: " <> ToString[MemoryInUse[] / 1024^3 // N] <> " Gb" // Print

memoryCleanupStart[] := Module[{},
  "Memory in use: " <> ToString[MemoryInUse[] / 1024^3 // N] <> " Gb" // Print;
  Unprotect@Out;
  CloseKernels[];
  ClearSystemCache[];
]

memoryCleanupFinalize[] := Module[{},
  Clear@Out;
  Protect@Out;
  LaunchKernels@useKernels;
  "Memory in use after cleanup: " <>
    ToString[MemoryInUse[] / 1024^3 // N] <> " Gb" // Print
]

useKernels = 2 * $ProcessorCount - 2;
launchNukes@useKernels;
SetSharedVariable@monitorCounter;

```

>> Import Images <<

Set the raw image folder:

imageFolder -- main folder with all experiments

subFolder -- experiment folder (all runs), i.e. "5p_4ul-min"

avoid extra pathname separators at the end of path strings

In[]:=

```
(*pixelSizeMicroMeters=0.064;
frameDurationMiliSeconds=50;
frameRate=1000/frameDurationMiliSeconds;*)

imageFolder := "D:\\[BIG DATA]\\ACTIVE - Data
  From Experiments\\MMML Data\\OOC Particle Flow\\[RAKSTAM]"

subFolder := "5p_4ul-min";
fileFolder = SetDirectory[imageFolder <> $PathnameSeparator <> subFolder];

First@StringSplit[#, "."] &@# & /@ SortBy[
  FileNames["*.tif"],
  ToExpression@FileName@# &
] // DeleteDuplicates // Sort
```

runID -- select the imaging run (focus plane) for processing

Example:

runID=4;

In[]:=

```

runID = 6;

runIdentifier = "run" <> ToString@runID <> ".";

files = Select[#, StringContainsQ@runIdentifier] &@SortBy[
  FileNames["*.tif"],
  ToExpression@FileName@# &
];

(*files=Sort@FileNames["*.tiff"]*)

files // Length
files[[1 ;; 25]]

output = mainOutputFolder <> $PathnameSeparator <> subFolder <>
  $PathnameSeparator <> StringDelete[runIdentifier, "."] <> $PathnameSeparator;
CreateDirectory@output; // Quiet

dataCSVfolder = output <> "CSV";
CreateDirectory@dataCSVfolder; // Quiet

dataCompressedfolder = output <> "Compressed Data";
CreateDirectory@dataCompressedfolder; // Quiet

```

In[]:=

```

monitorCounter = 0;

Monitor[
  images = ParallelMap[
    (monitorCounter++; Import[
      fileFolder <> $PathnameSeparator <> #,
      IncludeMetaInformation -> None
    ]) &, files
  ];, progress[monitorCounter, Length@files]
]

images = Last /@ images;
#@First@images & /@ {ImageDimensions, ImageType} // TableForm

```

Function Definitions

ALWAYS EVALUATE THESE CELLS

Image Filtering & Manipulation

```

backgroundBias = 10^-6;
placeholderBias = 10^-6;

```

```

viewImage[image_] := Image[image, ImageSize → Medium]
rotateImage[image_] := ImageRotate[#, rotationSwitch *  $\pi/2$ ] &@image

meanCorrection[image_, meanImage_] := image - meanImage // ImageAdjust

meanCorrectionFlat[image_, meanImage_] :=
  ImageMultiply[image, meanImage^(-1)] // ImageAdjust

applySCTMM[image_] := ImageAdjust@ImageMultiply[
  #, # - ColorNegate@ColorToneMapping[
    #, luminanceCompression, Method → "Luminance"
  ]] &@image

applyNMM[image_] := 2 * image - nonlocalCorrectionWeight * NonlocalMeansFilter[
  image, nonlocalCorrectionRadius, nonlocalNoiseFactor
] // ImageAdjust

preprocessImage[image_] := BrightnessEqualize[#+placeholderBias] &@
  ImageAdjust@ColorToneMapping@ImageAdjust@image

preprocessImageInverted[image_] := ColorNegate@preprocessImage@ColorNegate@image
applyCTMinverted[image_] := ColorNegate@ColorToneMapping@ColorNegate@image

globalFiltering[image_] := Nest[
  applyCTMinverted, #, preprocessPassesSecondary
] &@PeronaMalikFilter[
  #, peronaMalikIterations, peronaMalikConductivity
] &@applyNMM@Nest[ColorToneMapping, #, useCTMprimary] &@Nest[
  preprocessImageInverted, #, preprocessPassesPrimary
] &@ImageMultiply[ColorNegate@channelWallMask, #] &@image

globalSegmentation[image_] := SelectComponents[
  #, sizeMinimum < #Count < sizeMaximum &
] &@DeleteBorderComponents@Binarize[#, Method → "Entropy"] &@
  ImageMultiply[ColorNegate@channelWallMask, #] &@image

getImageDisplacementsMap[imagePair_] :=
  Image@Rescale@First@ImageDisplacements@imagePair

getChannelWallMask[image_] :=
  ImageSubtract[#, DeleteBorderComponents@#] &@Dilation[#, DiskMatrix@dilationScale] &@
    Closing[#, DiskMatrix@closingScale] &@
    Binarize@GaussianFilter[#, gaussianScale] &@LocalAdaptiveBinarize[
    applySCTMM@ColorNegate@#,
    adaptiveBinarizeScaleFactor * Median@ImageDimensions@# // N // Round
  ] &@ImageRotate[image, -rotationAngle]

```

Data Processing

```

exportImageSequence[images_, folder_, format_, compression_] := Module[
{
  imageSequence = images, exportFormat = format,
  exportFolder = folder, compressionLevel = compression, k, monitorCounter
},

monitorCounter = 0;

Monitor[
  For[k = 1, k ≤ Length@imageSequence, k++,
    Export[
      exportFolder <> $PathnameSeparator <>
        "Frame_" <> ToString@k <> exportFormat, imageSequence[[k]],
      CompressionLevel → compressionLevel
    ]; monitorCounter++;
  ], progress[monitorCounter, Length@imageSequence]
]; // AbsoluteTiming
]

exportImageSequenceWithSize[images_,
  folder_, format_, compression_, resolution_] := Module[
{
  imageSequence = images, exportFormat = format, exportFolder = folder,
  compressionLevel = compression, imageResolution = resolution, k, monitorCounter
},

monitorCounter = 0;

Monitor[
  For[k = 1, k ≤ Length@imageSequence, k++,
    Export[
      exportFolder <> $PathnameSeparator <>
        "Frame_" <> ToString@k <> exportFormat, imageSequence[[k]],
      CompressionLevel → compressionLevel, ImageResolution → imageResolution
    ]; monitorCounter++;
  ], progress[monitorCounter, Length@imageSequence]
]; // AbsoluteTiming
]

```

Plots

```
In[ ]:= getMaskOverlays[image_, mask_, color_, thickness_] := ImageAdd[
  ImageAdjust@image,
  ColorReplace[#, White → color] &@Binarize@GaussianFilter[#, thickness] &@
  EdgeDetect@mask
]

getLatexStyling[latexInput_] := MaTeX[#, FontSize → fontSize + 2] &@ (
  "\\boldsymbol{" <> ToString@# <> "}"
) &@latexInput
```

[[Image Preview]]

Defaults:

```
rotationSwitch=0;
rotationAngle= $\pi/2$ ;
```

```
In[ ]:= rotationSwitch = 1;
rotationAngle =  $\pi/2$ ;
```

```
In[ ]:= previewImages = images;
```

```
Manipulate[
  viewImage@rotateImage@(*ColorToneMapping@*) ImageAdjust@previewImages[[k]],
  {k, 1, Length@previewImages, 1}
]
```

Crop Images

Crop Images

Set Crop Boundaries

Defaults:

```
selectedImages=1;;All;
```

In[6]:=

```

selectedImages = 1 ;; All;

sequenceImages = images[[selectedImages]];

Manipulate[

  testImage = ImageAdjust@sequenceImages[[imageID]];
  {width, height} = ImageDimensions@testImage;

  Manipulate[
    Grid[
      {{
        Show[
          testImage,
          Graphics[
            {EdgeForm[{Yellow, Thickness@0.0035}],
              Opacity@0.10, Yellow, Rectangle@@points}
          ], ImageSize → 525
        ]},
      {
        Show[
          croppedImage = ImageTake[
            testImage,
            rowRange = Reverse[height - points[[All, 2]]],
            columnRange = points[[All, 1]]
          ], ImageSize → UpTo@450
        ]}}}
    {
      {points, {{0, 0}, {width, height}/2}}, Locator
    }
  ], {imageID, 1, Length@sequenceImages, 1}
]

```

Crop Images

Optional:

*For experiments with identical FOV for all runs,
 evaluate ‘{rowRange,columnRange}’ after setting crop boundaries;
 copy the output to the ‘memorizedRowColumnRanges’ definition
 Comment (disable, with “Alt + /”, enabling again works the same) the crop setter module
 Leave the ‘selectedImages’ and ‘sequenceImages’ definitions active*

```

(*{rowRange,columnRange}*)
(*memorizedRowColumnRanges={ {0,1024}, {350,847}};*)

```



```
(*{rowRange,columnRange}=memorizedRowColumnRanges*)
{rowRange, columnRange} // TableForm

Manipulate[
  rotateImage@ImageAdjust@Image[#, ImageSize → Medium] &@ImageTake[
    sequenceImages[[k]],
    rowRange, columnRange
  ],
  {k, 1, Length@sequenceImages, 1}
]
```

Defaults:

imageIndices=1;;All;

In[]:=

```
imageIndices = 1 ;; All;
```

In[]:=

```
croppedImages = ImageTake[#, rowRange, columnRange] & /@
  sequenceImages[[imageIndices]] // Parallelize; // AbsoluteTiming
```

```
First@croppedImages // ImageDimensions // TableForm
```

<< Export Cropped Images >>

In[]:=

```
croppedImagesFolder = output <> "1 Cropped Images";
croppedImagesFolder // CreateDirectory; // Quiet
```

```
exportImageSequence[
  croppedImages, croppedImagesFolder, ".tiff", 0
]; // AbsoluteTiming
```

>> Import Cropped Images <<

```

croppedImagesFolder = output <> "1 Cropped Images";
launchNukes@useKernels;
SetDirectory@croppedImagesFolder;

files = SortBy[
  FileNames[],
  ToExpression@FileBaseName@# &
];

monitorCounter = 0;

Monitor[
  croppedImages = ParallelMap[
    (monitorCounter++; Import[
      croppedImagesFolder <> $PathnameSeparator <> #,
      IncludeMetaInformation -> None
    ]) &, files
  ];, progress[monitorCounter, Length@files]
]

```

Image Projections & Correction

Image Stack Projections

Defaults:

```

rotationSwitch=1;
rotationAngle= $\pi/2$ ;
checkupIDs=1;;All;

```

In[]:=

```

rotationSwitch = 1;
rotationAngle =  $\pi/2$ ;
checkupIDs = 1 ;; All;

```

```

In[ ]:= imageStack = rotateImage@Image[ColorCombine@#, "Bit16"] &@croppedImages[[checkupIDs]]; //
  AbsoluteTiming
ToString@N[ByteCount@imageStack/1024^3] <> " Gb" // Print
memoryCheck[]

imageForms = Image[#, Byte] & /@ ImageAdjust /@ {
  rotateImage@First@#,
  rotateImage@Mean@#,
  ImageApply[Min, #] &@imageStack,
  ImageApply[StandardDeviation, #] &@imageStack
} &@croppedImages[[checkupIDs]]; // AbsoluteTiming

```

Defaults:

```

rotationSwitch=1;
useCTMprojections=1;

```

```

In[ ]:= rotationSwitch = 1;
useCTMprojections = 1;

In[ ]:= plotImageForms = GraphicsGrid[
  Rasterize[
    #, RasterSize → 0.5 * ImageDimensions@rotateImage@First@images
  ] & /@ Nest[ColorToneMapping, #, useCTMprojections] & /@ imageForms //
  Partition[#, 2] &,
  Dividers → All, ImageSize → Full, Dividers → All, Spacings → 5
]

In[ ]:= Export [
  output <> StringDelete[subFolder, $PathnameSeparator] <>
    "_OG_mean_min_stdev_projections.jpg",
  plotImageForms, CompressionLevel → 0
];

memoryCleanupStart[]
ClearAll /@ Unevaluated[{imageStack, checkupIDs}];
memoryCleanupFinalize[]

```

Particle Motion Check

```
In[ ]:= motionCheckSingleImage =
  #^(5/2) &@ColorToneMapping@HistogramTransform@First@croppedImages // rotateImage;

motionCheckImageStack = ColorToneMapping@#^(5/2) &@ColorToneMapping[
  Last@#/#[[3]] &@imageForms
];

plotMotionCheck = GraphicsColumn[
  {motionCheckSingleImage, motionCheckImageStack},
  ImageSize → Full, Dividers → All, Spacings → Scaled@0.025
]

In[ ]:= Export[
  output <> StringDelete[subFolder, $PathnameSeparator] <> "_motion_check.jpg",
  plotMotionCheck, CompressionLevel → 0
];
```

Image Correction (Optional)

Defaults:

useCTMcorrection=0; << 0 or 1
meanCorrectionIntervals={1;;All};
useFlatCorrection=0;

```
In[ ]:= useCTMcorrection = 1;
meanCorrectionIntervals = {1 ;; All};
useFlatCorrection = 1;
Length@meanCorrectionIntervals
```

```

In[ ]:= meanImages = Mean@croppedImages[ [# ] ] & /@meanCorrectionIntervals; // AbsoluteTiming
monitorCounter = 0;

Monitor[
  imagesCorrected = Flatten@Table[
    ParallelMap[
      (monitorCounter++;
        Nest[ColorToneMapping, #, useCTMprojections] &@ColorNegate@If[
          useFlatCorrection == 1, meanCorrectionFlat, meanCorrection
        ] [
          ColorNegate@#, meanImages[ [interval] ]
        ] ) &, croppedImages[ [# ] ] &@meanCorrectionIntervals[ [interval] ]
      ], {interval, 1, Length@meanCorrectionIntervals}
    ];, progress[monitorCounter, Length@Flatten@croppedImages]
  ] // AbsoluteTiming

In[ ]:= Manipulate[
  viewImage@rotateImage@ImageAdjust@imagesCorrected[ [k] ],
  {k, 1, Length@imagesCorrected, 1}
]

```

Particle CNR Boost & Detection

Segment Channel Boundaries

Things to adjust if necessary:

‘luminanceCompression’ -- for initial boundary segmentation

‘dilationScale’ -- controls the boundary-conformal cutoff buffer for artifact mitigation

‘adaptiveBinarizeScaleFactor’ -- for smoother (straighter) or finer-detailed boundary

‘detectChannelWalls’ -- set to 0 if the entire FOV is relevant, otherwise set to 1 to detect channel walls and create buffers

Defaults :

detectChannelWalls=0; < 0 or 1

luminanceCompression=0.5;

adaptiveBinarizeScaleFactor=0.5;

gaussianScale=2;

```

closingScale=5;
dilationScale=10;

```

```

In[ ]:= detectChannelWalls = 1;

luminanceCompression = 0.4;
adaptiveBinarizeScaleFactor = 0.75;
gaussianScale = 2;
closingScale = 5;
dilationScale = 20;

In[ ]:= channelWallMask = If[
    detectChannelWalls == 1,
    channelWallMask = getChannelWallMask@#,
    channelWallMask = Binarize[#, 1] &@ImageRotate[#, -rotationAngle]
] &@imageForms[[3]];

plotChannelWalls = GraphicsColumn[
    getMaskOverlays[
        #, ImageRotate[#, rotationAngle] &@channelWallMask, Red, 2
    ] & /@ {
        imageForms[[3]],
        preprocessImageInverted@rotateImage@First@imagesCorrected
    }, ImageSize -> Full, Dividers -> All, Spacings -> Scaled@0.025
]

channelWallMaskPhysical = Erosion[#, DiskMatrix@dilationScale] &@channelWallMask;

plotChannelWallsPhysical = getMaskOverlays[
    imageForms[[3]], rotateImage@#, Red, 2
] &@channelWallMaskPhysical;

viewImage@getMaskOverlays[#, rotateImage@channelWallMask, Yellow, 2] &@
plotChannelWallsPhysical

```

<< Export Channel Wall Mask >>

```

In[ ]:= MapThread[
    Export[output <> StringDelete[subFolder, $PathnameSeparator] <>
        "_channel_walls_mask_" <> #1, #2, CompressionLevel -> 0] &, {
        {".jpg", "physical.jpg", "binary.png", "binary_physical.png"},
        {plotChannelWalls,
         plotChannelWallsPhysical, channelWallMask, channelWallMaskPhysical}
    }];

```

[[Test Filter Output]]

Things to adjust if necessary:

preprocessPassesSecondary -- usually anywhere between 10 and 20

Default: 15; for 8 flow rates, might want 20

For cases with channel walls outside the FOV, can set to 0

Defaults :

preprocessPassesPrimary=2;

useCTMprimary=0;

nonlocalCorrectionRadius=2;

nonlocalNoiseFactor=1;

nonlocalCorrectionWeight=1.75;

peronaMalikConductivity=0.1;

peronaMalikIterations=2;

preprocessPassesSecondary=15;

{sizeMinimum,sizeMaximum}={5,50};

In[]:=

```
preprocessPassesPrimary = 2;
useCTMprimary = 0;

nonlocalCorrectionRadius = 2;
nonlocalNoiseFactor = 1;
nonlocalCorrectionWeight = 1.75;

peronaMalikConductivity = 0.1;
peronaMalikIterations = 0;

preprocessPassesSecondary = 15;
{sizeMinimum, sizeMaximum} = {0, 20};
```

Options :

testImages=croppedImages;

testImages=imagesCorrected;

```

In[ ]:= testID = 1;
testImages = imagesCorrected;

stage0 =
  rotateImage@ImageMultiply[ColorNegate@channelWallMask, #] &@testImages[[testID]];

stage1 = Nest[ColorToneMapping, #, useCTMprimary] &@Nest[
  preprocessImageInverted, #, preprocessPassesPrimary
] &@stage0; // AbsoluteTiming

stage2 = applyNMM@stage1; // AbsoluteTiming

stage3 = PeronaMalikFilter[
  #, peronaMalikIterations, peronaMalikConductivity
] &@stage2; // AbsoluteTiming

stage4 = Nest[applyCTMinverted, #, preprocessPassesSecondary] &@stage3; // AbsoluteTiming

stage5 = SelectComponents[
  #, sizeMinimum < #Count < sizeMaximum &
] &@DeleteBorderComponents@Binarize[#, Method → "Entropy"] &@ImageMultiply[
  rotateImage@ColorNegate@channelWallMask, #] &@stage4; // AbsoluteTiming

Partition[#, 2] &@{
  stage0, stage1, stage2, stage3, stage4, stage5
} // GraphicsGrid[#, ImageSize → Full, Dividers → All, Spacings → Scaled@0.025] &

HighlightImage[stage4, ImageMarker[stage5, "Circle"]]

```

Process Images

```

In[ ]:= monitorCounter = 0;

Monitor[
  imagesFiltered = ParallelMap[
    (monitorCounter++; globalFiltering@#) &, testImages
  ];, progress[monitorCounter, Length@testImages]
] // AbsoluteTiming

monitorCounter = 0;

Monitor[
  particleMasks = ParallelMap[
    (monitorCounter++; globalSegmentation@#) &, imagesFiltered
  ];, progress[monitorCounter, Length@imagesFiltered]
] // AbsoluteTiming

```


[[Preview Results]]

```
In[ ]:= Manipulate[
  viewImage@rotateImage@imagesFiltered[[k]],
  {k, 1, Length@particleMasks, 1}
]

Manipulate[
  viewImage@rotateImage@particleMasks[[k]],
  {k, 1, Length@particleMasks, 1}
]
```

<< Export Filtered Images & Particle Masks >>

```
In[ ]:= filteredImagesFolder = output <> "2 Filtered Images";
filteredImagesFolder // CreateDirectory; // Quiet

exportImageSequence[
  imagesFiltered, filteredImagesFolder, ".tiff", 0
]; // AbsoluteTiming

filteredImagesFolder = output <> "2 Filtered Images Compressed";
filteredImagesFolder // CreateDirectory; // Quiet
imagesFilteredCompressed = Compress /@ imagesFiltered // Parallelize; // AbsoluteTiming

exportImageSequence[
  imagesFilteredCompressed, filteredImagesFolder, ".txt", 1
]; // AbsoluteTiming

particleMasksFolder = output <> "3 Particle Masks";
particleMasksFolder // CreateDirectory; // Quiet

exportImageSequence[
  particleMasks, particleMasksFolder, ".tiff", 0
]; // AbsoluteTiming

particleMasksFolder = output <> "3 Particle Masks Compressed";
particleMasksFolder // CreateDirectory; // Quiet
particleMasksCompressed = Compress /@ particleMasks // Parallelize; // AbsoluteTiming

exportImageSequence[
  particleMasksCompressed, particleMasksFolder, ".txt", 1
]; // AbsoluteTiming

memoryCleanupStart[]
ClearAll /@ Unevaluated[{imagesFilteredCompressed, particleMasksCompressed}];
memoryCleanupFinalize[]
```

>> Import Compressed Filtered Images <<

```

In[ ]:= filteredImagesFolder = output <> "2 Filtered Images Compressed";
launchNukes@useKernels;
SetDirectory@filteredImagesFolder;

files = SortBy[
  FileNames[],
  ToExpression@FileName@# &
];

monitorCounter = 0;

Monitor[
  imagesFiltered = ParallelMap[
    (monitorCounter++; Uncompress@Import[
      filteredImagesFolder <> $PathnameSeparator <> #,
      IncludeMetaInformation -> None
    ]) &, files
  ];, progress[monitorCounter, Length@files]
]

In[ ]:= Manipulate[
  viewImage@rotateImage@(*ColorToneMapping@*) ImageAdjust@imagesFiltered[[k]],
  {k, 1, Length@imagesFiltered, 1}
]

```

>> Import Compressed Particle Masks <<

```

In[ ]:= particleMasksFolder = output <> "3 Particle Masks Compressed";
launchNukes@useKernels;
SetDirectory@particleMasksFolder;

files = SortBy[
  FileNames[],
  ToExpression@FileName@# &
];

monitorCounter = 0;

Monitor[
  particleMasks = ParallelMap[
    (monitorCounter++; Uncompress@Import[
      particleMasksFolder <> $PathnameSeparator <> #,
      IncludeMetaInformation -> None
    ]) &, files
  ];, progress[monitorCounter, Length@files]
]

```

Particle Coordinates & Data for Tracking

Get Particle Coordinates

```

In[ ]:= monitorCounter = 0;

Monitor[
  particleCentroids = (monitorCounter++;
    (Last /@ ComponentMeasurements[#, "Centroid"])
  ) & /@ particleMasks // Parallelize;,
  progress[monitorCounter, Length@particleMasks]
] // AbsoluteTiming

(*ListLinePlot[
  Length@particleCentroids, FrameLabel->getLatexStyling/@"t", "N"
]

Manipulate[
  rotateImage@HighlightImage[#, Style[particleCentroids[[k]], PointSize@0.005]
    ]&@getMaskOverlays[#, channelWallMask, White, 2]&@imagesFiltered[[k]],
  {k, 1, Length@particleCentroids, 1}
] *)

```

<< Export Particle Coordinates >>

```

In[ ]:= Export[
  dataCompressedFolder <> $PathnameSeparator <> "Particle Centroids.txt",
  Compress@particleCentroids
];

```

>> Import Particle Coordinates <<

```

particleCentroids = Uncompress@Import[
  dataCompressedFolder <> "Particle Centroids.txt"
];

```

Export Notebook With Parameters

```
In[ ]:= notebookID = 1;

(*FrontEndTokenExecute["DeleteGeneratedCells"];*)
NotebookSave[];
notebookSnapshot = NotebookOpen@NotebookFileName[];

Export[
  output <> Last@StringSplit[#, $PathnameSeparator] &@output <>
  "_Run_" <> ToString@notebookID <> ".pdf", notebookSnapshot
];
```